

Engineered Solutions. Trusted Results.

ACCESSORIES

2 Bar Hinge Stops



Hinge stops are used to provide a secondary level of security for 2 bar casement and awning hinges. They keep the slide shoe from becoming dislodged from the track if the support arm would be inadvertently disconnected from the track stud. We recommend that they be applied to both hinges on a casement or awning window where additional security is desired.

Our 2 bar hinge tracks all have a mounting hole which is designed to be used with this stop accessory.

Available Colors



Stainless Steel